

Remote Control Adapters

DB Pins	Description	Part #
DB9	DB9M User Programmable	13509
DB9	DB9F User Programmable	14282
DB9	Sony CPP-D11 CD Player	9996
	Sony CDR-W66 CD Recorder	
DB9	Telos One-x-Six	14534
DB9	Sony MDS-E12 MD Recorder	14710
DB9	Vox Pro CD	14990
DB9	Telos One Hybrid	14996
DB9	Telos 100	15051
DB9	SAS Turret and Desktop RS-485 Panels	15257
DB9	Millenium D RS-232 Adapter	15329
DB9	RS-232 Data (null-modem adapter)	15749

DB15	DB15M User Programmable	13508
DB15	DB15F User Programmable	14315
DB15	Tascam CD-01U & CD-01UPro CD Player	12789
DB15	Tascam DA-40 DAT Recorder	14532
DB15	Tascam CD-RW2000 CD-R Recorder	14706
DB15	360 Systems Shortcut	14709
DB15	Telos TWOx12 Multi-Line Talk Show System	14893
DB15	Tascam CD-A700 CD Player	15212
DB15	Starguide III Receiver	15981
DB15	Axia GPIO Node	15355

DB25	DB25M User Programmable	13507
DB25	DB25F User Programmable	14316
DB25	Airtools 6100 Delay	12799
DB25	Denon DN-961FA CD Player	14533
DB25	Tascam 122MK122MKII Cassette Player	14535
DB25	Denon DN-C630/635/680 CD Player	14705
DB25	Telos 2101 Telephone Hybrid	14707
DB25	Marantz PMD325 CD Player	14829
DB25	DI-2000 Telephone Hybrid (Intelligent)	14920
DB25	DI-2000 Telephone Hybrid (Basic)	14923
DB25	360 Systems Digicart	14992
DB25	Marantz PMD331 CD Player	14993
DB25	Gentner SHP-31 Telephone Hybrid	15197
DB25	Comstream ABR-200	15982
DB25	Evenited Delay Auxiliary Control Connector	15744
DB25	SH+ BEI Remote Adapter	15989

8 Pin DIN	Sony PCM R500-R700 DAT Recorder	14048
8 Pin DIN	Panasonic SV-3700/4100 DAT Recorder	14708
8 Pin DIN	Sony PCM R500-R700 DAT Recorder	14994 (20 ft. Cable)
		14995 (12 ft. Cable)
8 Pin DIN	HHB CDR830PLUS CD Recorder	15029